




Disassembling Canon PowerShot SD1100 IS AV port and Logic board

Written By: Dozuki System



INTRODUCTION

Use this guide to remove the AV port and logic board.

TOOLS:


- [Phillips #00 Screwdriver](#) (1)
 - [Spudger](#) (1)
 - [Tweezers](#) (1)
-

Step 1 — Disassembling Canon PowerShot SD1100 IS AV port and Logic board




- Remove wrist strap and battery.

Step 2



- Remove 2 screws from each side of the camera (4 total, 0.102 in).
 - Remove 2 screws from the bottom on the camera (0.138 in).
- ⚠ Do not mix the 4 side screws with the 2 bottoms ones; they are different sizes.

Step 3





- Gently pull off the front cover.
- ⓘ The plate on the side should come off.
- Gently pull off the back cover.

Step 4





- The cases should now be removed.

Step 5





- Remove the top-left screw above the LCD screen (0.100 in).
- Remove the C-shaped plate from the side of the LCD screen.

Step 6




- Remove the screw from the top-right of the LCD screen (0.098 in).
- Remove the L-shaped bar from the right of the LCD screen.

Step 7



- Use the spudger to remove the L-shaped bar from the left-side of the LCD screen.

Step 8




- Use tweezers to remove the connector ribbon from the top-left corner above the LCD screen.
- ⚠ Be gentle. This ribbon should stay attached to the screen.

Step 9




- Use a spudger to lift the connector lock (black flap) at the end of the larger LCD connector ribbon on the front side of the camera.
- Use the tweezers to lift this ribbon.
- Use the tweezers to gently peel this ribbon from the one underneath it.

Step 10



- The LCD screen should now be removed.

Step 11





- Remove the screw located on the side of the camera (0.072 in).

Step 12




- Use the spudger to remove the lens ribbon from the circuit board.
- Use the spudger to lift the ribbon.
- ⓘ This ribbon is connected to the lens, but the flash assembly ribbon is underneath it.

Step 13




- Disconnect the flash assembly ribbon.
- ⓘ The flash assembly ribbon is located underneath the lens assembly ribbon.

Step 14




- Remove the flash assembly, which includes the capacitor. If it resists, note the small hook on the right side near the bottom.
- ⚠ Be careful when taking out the capacitor. It could shock you.

Step 15





- The capacitor should now be removed.

Step 16




- Remove 4 screws from silver plate (0.106 in).

Step 17





- Use spudger to lift the second lens ribbon.
- ⓘ Remember the first ribbon was removed while taking out the flash assembly.

Step 18




- Use spudger to carefully lift the LED light off the upper-left corner of the lens.

Step 19





- Remove the lens.

Step 20





- The camera lens should now be removed.

Step 21



- Remove screw from top-right of logic board (0.102 in).
- Remove screw on the silver plate (0.102 in).


Step 22



- Remove screw from bottom-right of logic board board (0.102 in).



i The tripod connector can now be removed.

Step 23





- Remove screw (0.102 in) from the left side of the logic board.

Step 24






- Using the spudger, disconnect the ribbon cable located on the top of the logic board.

Step 25




- The logic board may now be removed from the frame.

Step 26



- Remove the remaining screw (0.102 in) located on the camera strap piece.
- The camera strap piece and the av port/battery/memory card assembly can now be removed.

Step 27



- This is the final product.

To reassemble your device, follow these instructions in reverse order.