



Canon Powershot SD750 Battery Replacement

Written By: Dozuki System



INTRODUCTION

This guide will teach you how to change the Canon PowerShot SD750 battery.

Step 1 — Canon Powershot SD750 Battery Replacement



- Open the latch on the bottom of the camera by applying pressure to the latch and sliding it to the right.
- Insert or remove the battery through this opening.

To reassemble your device, follow these instructions in reverse order.