

Server

Written By: Tobias Isakeit



INTRODUCTION



Dismantling and Recycling Centre (DRZ)

Katharina Lenz, Vienna / Austria

Health & Safety

Dismantling doesn't include any harmful steps. Nonetheless workers should wear personal protection equipment like gloves, goggles, apron and robust shoes.

Note: This is a general guide for most servers. As the construction can differ, the dismantling steps mentioned below can vary in their order. However, the described steps show what parts the removal should focus on.



TOOLS:

- Several screwdrivers (T1) (1)
- Flathead Screwdriver (T2) (1)
- Hammer (T3) (1)
- Side cutter (T4) (1)
- Pliers (T5) (1)
- Industrial scale (T9) (1)

Step 1 — Server








Remove the batteries.

Step 2



Store the lead batteries safely.







Open the case.








- Remove the cooling fans.
- If the fans don't come out easily, hammer them out.




Remove the power supply element.

Step 6




Unplug and remove the wires.



Unscrew and remove the electronic parts.

Step 8



Remove the aluminium heat sinks.



Unscrew the electronics.

Step 10



Cut the wires off the electronics.



Remove the RAMs.

Step 12






Remove the CPUs.



Pry out the cmos battery.

Step 14



Unclip the wires.





Remove the disk drives.





- Unscrew the mount.
- Remove the battery cases.



Remove the aluminium parts.

Step 18





Unscrew the PWB.






Remove the metal parts.

Step 20





Unscrew the aluminium parts.





- Remove the wires.
- Unscrew the plugs.








- Remove all the plastic parts.
- Remove the PWB.





- Separate the remaining materials according to their type and go on with the appropriate data sheet (e.g. aluminium, ferrous metals, plastic, further PWBs, etc.).
- Make sure the plastic parts are completely free of metal pieces.