PSP Go Trigger buttons Replacement

Written By: Dozuki System



This document was generated on 2020-11-15 02:59:16 AM (MST).

INTRODUCTION

This guide shows you how to remove the PSP Go's trigger buttons.

Note: The procedure is exactly the same for the both left and right trigger buttons.

TOOLS:

- Phillips #00 Screwdriver (1)
- Plastic Opening Tools (1)

PARTS:

- Sony PSP Go Left Trigger Button (1)
- Sony PSP Go Right Trigger Button (1)

© 2020

Step 1 — PSP Go Trigger buttons Replacement





- Unscrew the four Phillips screws on the back of the PSP Go.
- Rotate the PSP so you can see the top of the device.
- Unscrew the two Phillips screws next to the volume buttons.

Step 2





- Use a plastic opening tool around the perimeter of the back cover to loosen it on all sides.
- Open the back cover by gently lifting the right side, and rotating it to the left side (as if you were opening a book).

⚠ Be careful not to rotate the back cover from the bottom, as you will break the plastic screw holes on top of the device.

Step 3



- Pull the top cover upwards gently from its housing.


Step 4



- The top cover will most likely come off during the repair, so might as well take it off now. Pull it upwards gently from its housing.

© 2020

Step 5



The procedure is exactly the same for the left trigger button.

- Use a plastic opening tool to gently flip up the left trigger connector.

Step 6





- Unscrew the lone Phillips screw holding the trigger in place. Remove both trigger and retaining plate from the PSP Go.

If necessary, repeat steps 2 and 3 to remove the right trigger button.

To reassemble your device, follow these instructions in reverse order.

© 2020