



MacBook Air 11" Late 2010 Lower Case Replacement

Written By: Dozuki System



INTRODUCTION

Remove the lower case to access the internals of your MacBook Air.



TOOLS:

- [P5 Pentalobe Screwdriver Retina MacBook Pro and Air](#) (1)



PARTS:

- [MacBook Air 11" \(Late 2010/Mid 2011\) Lower Case](#) (1)

Step 1 — MacBook Air 11" Late 2010 Lower Case Replacement



- ✦ Before proceeding, close your computer and lay it on a soft surface top-side down.
- Remove the following ten screws:
 - Two 8 mm 5-point Pentalobe screws
 - Eight 2.5 mm 5-point Pentalobe screws
- i The special screwdriver needed to remove the eight 5-point Pentalobe screws can be found .

Step 2



- Wedge your fingers between the display and the lower case and pull upward to pop the lower case off the Air.
- Remove the lower case and set it aside.

To reassemble your device, follow these instructions in reverse order.