



PSP Go Back Cover Replacement

Written By: Dozuki System



INTRODUCTION

This guide shows you how to remove the PSP Go's back cover.



TOOLS:

- [Phillips #00 Screwdriver](#) (1)
- [Plastic Opening Tools](#) (1)



PARTS:

- [Sony PSP Go Back Cover](#) (1)

Step 1 — PSP Go Back Cover Replacement



- Unscrew the four Phillips screws on the back of the PSP Go.
- Rotate the PSP so you can see the top of the device.
- Unscrew the two Phillips screws next to the volume buttons.

Step 2



- Use a plastic opening tool around the perimeter of the back cover to loosen it on all sides.
 - Open the back cover by gently lifting the right side, and rotating it to the left side (as if you were opening a book).
- ⚠ Be careful not to rotate the back cover from the bottom, as you will break the plastic screw holes on top of the device.

To reassemble your device, follow these instructions in reverse order.