



# PSP Go Top Cover Replacement

Written By: Dozuki System



---

## INTRODUCTION

Use this guide to replace your PSP Go's top cover.



### TOOLS:

- [Phillips #00 Screwdriver](#) (1)
  - [Plastic Opening Tools](#) (1)
-

## Step 1 — PSP Go Top Cover Replacement



- Unscrew the four Phillips screws on the back of the PSP Go.
- Rotate the PSP so you can see the top of the device.
- Unscrew the two Phillips screws next to the volume buttons.

## Step 2



- Use a plastic opening tool around the perimeter of the back cover to loosen it on all sides.
  - Open the back cover by gently lifting the right side, and rotating it to the left side (as if you were opening a book).
- ⚠ Be careful not to rotate the back cover from the bottom, as you will break the plastic screw holes on top of the device.



## Step 3



- Pull the top cover upwards gently from its housing.

To reassemble your device, follow these instructions in reverse order.