



# Toshiba Satellite 1805-S177 Battery Replacement

Written By: Dozuki System



## INTRODUCTION

If your battery no longer holds charge, it is a wise decision to purchase a new battery and replace the old one. This guide will show you how to replace this battery.

## Step 1 — Toshiba Satellite 1805-S177 Battery Replacement



- Placing your finger on the raised grip, push the battery casing to the right. It will slide over.

## Step 2



- Pull the battery casing gently out toward yourself, until you hear a clicking sound.
- ① The battery should pull out to about 2 inches.

## Step 3



- Lift the battery casing out of the laptop.

To reassemble your device, follow these instructions in reverse order.