



Canon Optura 100MC Hand Strap Replacement

Written By: Dozuki System



INTRODUCTION

Use this guide to replace your hand strap.



TOOLS:

- [Phillips #00 Screwdriver](#) (1)
-

Step 1 — Canon Optura 100MC Hand Strap Replacement



- Orient the camera with the hand strap facing you.
- Remove the two 4mm #00 Philips screws.
- ❗ When the screws are removed, the black plate will easily come off as well as the two metal plates under it. Be careful to not let them fall or get lost.

Step 2



- Lift the strap up.

To reassemble your device, follow these instructions in reverse order.