



# Disassembling IBM ThinkPad A30 Battery


Written By: Dozuki System



# INTRODUCTION

This guide will show you how to remove the battery for the ThinkPad A30.

## Step 1 — Disassembling IBM ThinkPad A30 Battery



- ❗ Flip the ThinkPad over so that it is upside down.
- Slide the highlighted tab to the left.
- With your finger on the tab, remove the battery by lifting it upwards away from the laptop.

To reassemble your device, follow these instructions in reverse order.