



iBook G4 14" 1.42 GHz Battery Replacement

Written By: Dozuki System



INTRODUCTION

Changing the battery is easy -- all you need is a coin.


 **TOOLS:**

- Coin (1)

 **PARTS:**

- iBook G4 14" Battery (1)

Step 1 — iBook G4 14" 1.42 GHz Battery Replacement



- Use a coin to rotate the battery locking screw 90 degrees clockwise.
- Lift the battery out of the computer.

To reassemble your device, follow these instructions in reverse order.